



## PEG OPC DRUM LIST

### HP

For use in	Type	Code
HP LJ 5L/5ML/LJ6L/6Lpro/6Lgold/6Lse/6LXI/6Pse/6PSI; HP LJ1100/1100A/3100/3150/3150Se/Xi/3200/Se/M	3906F	PEG001
HP LJ 1000/1005/1200/1220,3300/3310/3320/3330/3380	7115A	PEG002
HP LJ 2100/N/TN/SE/XI; 2200/Dose/DT/DEN/DEN	96A	PEG003
HP LJ 4000/N/T/TN,4050/N/T/TN/se	4127X	PEG004
HP LJ 5P/5VP/6P/6VP	3903F	PEG005
HP LJ 4100/N/TN/TEN	8061X	PEG011
HP LJ 850/5000/N/GN/TN/DTN,5100	4129X	PEG012
HP LJ 8100/N/DN/8150/N/DN/HN/MFP;Mbpier 320	4182X	PEG013
HP LJ 5Si/5SiMK/5Si Mbpier/5Si NX,HP-LJ8000/Mbpier 240MK	3909A	PEG014
HP LJ 4V/4W	3900A	PEG015
HP LJ3Si/4Si;	NX	PEG019
HP LJ 1150	2624A	PEG020
HP LJ 1300/N/Se	2613A	PEG022
HP LJ4200/N/TN/DEN/DENS/4250	1338A	PEG023
HP LJ4300/N/TN/DEN/DENS/4345/4350	1339A	PEG024
HP LJ9000/N/DN/HNS/MFP/9050/n/dn	8543X	PEG025
HP LJ2300/L/d/n/den/den	2610A	PEG026
HP LJ1010/1012/1015/1018/1020/1022/3015/3020/3030/ M1005/3050/3052/3055	2612A	PEG027
HP LJ2400/2410/2420/2430	6511A	PEG029
HP LJ1320/1160/3390/3392	5949A	PEG030
HP LJ5200	7516A	PEG053
HP Color LaserJet 1600/2600/2605	2600	PEG049
HP Color LaserJet 3500/3700	3500	PEG050
HP Color LaserJet 4600/4650	4600	PEG051
HP Color LaserJet 5500 /5550	5500	PEG052
HP P2014/P2015 Series	7553X	PEG055
HP P3005 Series , MFP 3027/3035	7551X	PEG056
HP LaserJet M1120/M1120N/M1522nf/M1522n/P1505/P1505N	436A	PEG061
HP LaserJet P1005/1006/1007/P1008	388A	PEG062
HP Color LaserJet CP1215/CP1515n/CP1518ni/CM1312	CP1215	PEG063
HP LaserJet P4014/4015/4515	364A	PEG064
HP LaserJet P2035/2055	505X	PEG057
HP Color LaserJet CP3525	250-253	PEG058

Print Engine Grasp

[www.peg-c.com](http://www.peg-c.com)



## PEG OPC DRUM LIST

### Canon

For use in	Type	Code
Canon LBP-AX/350/440/460/465/660/800/1120/22X/EP-22, Laser Class 2060/3500/4000/4500/Canon FX3	3906F	PEG001
Canon LBP-1210/3200/3210/FX8/MF3220/5770,EP-25/EP26/EP27, ImageClass D320/D340(S-35)/D380(cartridge U/M)	7115A	PEG002
Canon Laser Class 3170/3175(FX6), Canon LBP-1760/P370/52X	4127X	PEG004
Canon FX4; Canon Laser Class 9000; Canon LBP-VX	3903F	PEG005
Canon LBP-62X/1620/1820/840/850/880/910,EP-62	4129X	PEG012
Canon LBP-2460;LBP-VX	3909A	PEG014
Canon LBP-BX/BX	3900A	PEG015
Canon LBP-NX/LBP-NX 600/P-170	NX	PEG019
Canon LBP-2900/3000/3200/MF4270/4330/4370/EP- 26/catridge303/FX9/FX10	2612A	PEG027
Canon LBP3460/6280K/6330K	6511A	PEG029
Canon LBP3300/3310/3360/3370(cartridge308/ 315/508)	5949A	PEG030
Canon LBP-5000/5100(cartridge307)	2600	PEG049
Canon LBP-2510/5500,EP-85	4600	PEG051
Canon LBP-3500/3900/3950(cartridge 309/509)	7516A	PEG053
Canon LBP-3018/3100/3108(cartridge 912)	388A	PEG062
Canon LBP-5050(cartridge 316)	CP1215	PEG063

### Epson

Epson LP-800/S/900/1200/1300/U/1800/1900/N/2200/2400; Epson EPL-5500/N/5700/5800/5900/L/6100/L	SP302	PEG017
Epson LP-7700/8100/8700/8700 PS3/8900/EPL2120	LP8100	PEG033
Epson LP-8200/8200PS/8300	LP8200	PEG034
Epson LP- 8300S/8300F/8400FX/FXN/8600/F/FX/FXN/8300F/S/2010/1610/1210	LP8400	PEG035
Epson LP-9600/EPL-N4000	N24	PEG037
Epson LP-9400	LP9400	PEG038
Epson EPL-1220; LP7100	N2300	PEG039
Epson EPL6200/L	EP6200	PEG040
Epson C3800	C2100	PEG070
Epson C1000/C2000	Q2200	PEG087
Epson LP-9200/EPL-N2000/N2000	LP9200	PEG089
Epson Aculaser C900/C1900	Q2300	PEG093
Epson LP-9300/EPL-N2700/2750	LP9300	PEG094

Print Engine Grasp

[www.peg-c.com](http://www.peg-c.com)



## PEG OPC DRUM LIST

### Brother

For use in	Type	Code
Brother HL-1260/1660(EX)	98A	PEG007
Brother HL-4/4PS/4V/4Ve/6/6V	75A	PEG008
Brother HL-8/8E/8PS-AP/8D-AP/8V/HL-10	95A	PEG009
DR400/DCP-1200/1400 HL-1230/1240/1250/1270/N/1440/1450/1470N/ MFC-8300/8600/8700/9700/9800;DR500/Brother HL- 1650/N/1670/1850/1870N/ 5040/5050/LT/5070N/MFC-8420/8820D/DN	B1240	PEG066

### Samsung

Samsung SF-5000	P8E	PEG010
Samsung ML- 200/250/1010/1210/1220/1250/1430/4300/4500/4600/SF550	LE210	PEG016
Samsung ML-1610/2010/2510/2570/2571N,SCX4321/4521	ML1610	PEG031
Samsung ML8200/8250/8600/8650/8700	N2300	PEG039
Samsung ML2150/2151N/2152N/2550/2551N/2552N	ML2150	PEG041
Samsung ML3050/3051	ML3050	PEG081
Samsung ML-3560/3561N/3561ND/3562N	ML3560	PEG082
Samsung ML-2851/2852 <b>NEW</b>	ML2851	PEG083
Samsung ML-700/1510/1520/1710/1740/1750/SF560; SCX-4100/4200/4116/4216F;	ML1710	PEG090
Samsung ML-1440/1450/1650/1651N/6000/6060/6085/6160N/S	ML1650	PEG095
Samsung ML5100/530	ML5100	PEG096
Samsung ML-2250/2251, SCF-4520/4720	ML2250	PEG097
Samsung ML-1641/2241/2245	108S	PEG084
Samsung SCX-6120/6220/6320	ML6320	PEG085

### Lexmark

Lexmark Optra E310/E312/E312L	P8E	PEG010
Lexmark 4040/Optra N240/245	09A	PEG014
Lexmark Optra E210	LE210	PEG016
Lexmark Optra E /E+/Ep/Es/4026/4026A/B/D/E;	SP302	PEG017
Lexmark W812	LP8100	PEG033
Lexmark W820/N/DN/E	N24	PEG037
OptraS1250/1250N1255/1620/1625/1650/1650N/1855/2420/2450/2450N /2455;Optra Image222/322/5240	S	PEG048
Lexmark E120	E120	PEG046
Lexmark T4 20/T430	T420	PEG059
Lexmark E230/232/330/332/250	E230	PEG060
Lexmark X215, RICOHAC104	ML1710	PEG090

Print Engine Grasp

[www.peg-c.com](http://www.peg-c.com)



## PEG OPC DRUM LIST

### IBM

For use in	Type	Code
IBM4324, IBM Network Printer 24/24-PS; Interface System 9324	09A	PEG014
IBM 5585	KX	PEG021
IBM InfoPrint 24/32/40/1145/4324/4332	N24	PEG037
IBM 4059, Infoprint 1120/1125/1140	S	PEG048
IBM 1412	E230	PEG060
IBM InfoPrint 12	ML1650	PEG095

### Minolta

QMS 2425/2425EX, FX-1/2425 FX- 2/2425EX	3909A	PEG014
QMS PS 860/1660;	3900A	PEG015
Minolta 1100W/1200W/1300W/1350;Minolta SP-302/PagePro 6e/6L/Pageworks 6e/6l/Fax 2500/3500/5500	SP302	PEG017
QMS 1700/1725/PS1700/PS1725/1725SLS PS	NX	PEG019
Minolta SP1000/1500/1700/SP6; QMS1060	LP8200	PEG034
Minolta 270/280/290/310	W810	PEG047
QMS 3260/4032	N24	PEG037
QMS 2200	Q2200	PEG087
Minolta SP A-310, Pageworks20, Page Pro 20; QMS2060	LP9200	PEG089
QMS 2300/2400	Q2300	PEG093

### Pitney

Pitney Bowes 9700/9720/9750/9760	XP5	PEG032
Pitney Bowes 9900/9910/9920/9930/9950/2000/2030/2050; DX-1000/DX-2000	UG3313	PEG042
Pitney Bowes 9800/9820/9830	UG3309	PEG043
Pitney Bowes 1530	UG3350	PEG044

### Panafax

Panafax UX745/755/755E	XP5	PEG032
Panafax GX-3100	N24	PEG037
Panasonic panafax UF-550/650/850/770/880/885/895/DF1100/UG3313	UG3313	PEG042
Panafax UF-744/788 UG3309/3317	UG3309	PEG043
Panasonic panafax UF-585/595/UG3350(PB-1530)	UG3350	PEG044
FL501/502/503/523/FLM551/552/553/FLB751/752/753/755/756/758/FA77/78A/KX-FP503/526	PA77A	PEG045
FL511/512/513	84E	PEG054



## PEG OPC DRUM LIST

### Xerox

Xerox DocuPrint P8e/ex; Xerox WbrkCentre 385/390	P8E	PEG010
Xerox Phaser 3110	LE210	PEG016
Xerox 6R901	NK	PEG019
Xerox 4505/4510/4520/PS; Fuji-Xerox 5/10/P1	XP5	PEG032
Xerox Docu Print 210/211	LP8100	PEG033
Xerox Docu Print N2025/2825	LP8400	PEG035
Xerox XE60/62/80/82/84/90fx; P8	XE60	PEG036
Fuji-Xerox 128/Hodaka 2/ABLE3401; Xerox Docu Print N24/N32/N40/N4525/DX/CX/FN	N24	PEG037
Xerox Phaser 3450	ML2150	PEG041
Xerox Phaser 3400b/3400N/Docuprint P1210	ML1650	PEG095
Xerox Phaser 3115/3116/3120/3121/3130, PE16	ML1710	PEG090
Xerox Phaser 3117/3122, PE220	ML1610	PEG031
Xerox C2100	C2100	PEG070
XEROX 3428	ML3050	PEG081
Xerox Phaser 3150/Xerox PE 120	ML2250	PEG097
Xerox WorkCentre M20 <b>Developing</b>	ML6320	PEG085

### Others

Wang LDP-17; Alcatel v8376	NK	PEG019
DELL 1100	ML1610	PEG031
Gcc Elite 600/ET; Dec Declaser 3500M/N	XP5	PEG032
Lenevo 7500	LP8100	PEG033
Founder A6000/1210; Lenovo 4B/6C/6C+; APTi Powerlaser E740H	LP8200	PEG034
Lenevo 3116	LP8400	PEG035
Sharp JX-9200/DR92/AL-800/FO-2600/2800/3800	XE60	PEG036
Compaq LN32; Genlcam microlaser320; Dataproducts DDS32/40; Fujitusu LB303/306A	N24	PEG037
Lenevo 5500; Founder A6100/A6100U/A6100N	N2300	PEG039
Dell 1700	E230	PEG060
Lenovo 2312/2500	B1240	PEG066
DELL C3110	C2100	PEG070
Lenevo C8000	Q2300	PEG093
DELL 1600	ML2250	PEG097
OKI C5100n/C5150n/C5200n/C5300n/C5400	OKI5100	PEG099
OKI C3300n/C3400n/C3450	OKI3400	PEG100

Print Engine Grasp

[www.peg-c.com](http://www.peg-c.com)

